


Supplementary Guide – WWVDS Camera Password Retrieval


How to Retrieve the WWVDS Camera Password

This is a step-by-step guide on how to remotely locate and retrieve the camera password for GovComm Wrong Way Vehicle Detection Systems (WWVDS).

Step 1 – Log into WWVDS Web Interface and download configs.zip File




- Navigate to Configuration → Maintenance → Export Configuration Settings, then click the Export button.
- Download configs.zip file.



Step 2 – Extract configs.zip file and open cameras.json file

- Extra zip file downloaded.
- Open cameras.json
- locate the RTSP links for installed cameras and identify associated username and password.
 - `rtsp://<username>:<password>@<ipaddress>:554/snl/live/1/1`



```
{
  "list_camera": [
    {
      "cam_ID": 1,
      "cam_Name": "Detection Camera - Visual",
      "cam_Link": "rtsp://admin:Password@10.10.XXX.XXX:554/snl/live/1/1",
      "big_zone": "9,714,354,718,845,369,481,362,6,465",
      "video_out": "",
      "images_out": "",
      "json_out": "output/jsons",
      "record_camera": {
        "url": "rtsp://admin:Password@10.10.XXX.XXX:554/snl/live/1/1",
        "time_record": 15,
        "nr_of_pictures": "10",
        "time_between_front_rear": "5",
        "detection_timeout": "30",
        "big_zone":
          "257.611083984375,608.5794324072722,1252.2777506510417,538.5981239960572,1102.9444173177083,399.98130156615065,513.611083984375,268.0934510988609,31770834,293.6635445568049,156.27775065104166,527.8317688558703",
        "list_zone": [

```